

## ◆→ **SILICONE FIREPROOF SEALANT**

Hawke Silicone Fireproof Sealant (Ref. 962) is used to secure installation in marine bolted frames and civil bolted frames and sleeves.

Fireproof sealant should be applied between the flange of the frame and the structure to ensure a tight seal and avoid possible gaps.



## ◆→ **MASTIC**

Hawke Mastic (Ref. 966) is used to secure installation in civil bolted frames and sleeves.

Mastic should be applied between the flange of the frame and the structure to ensure a tight seal and avoid possible gaps.

