







Check that HTS Sleeve has been used in the installation, that it has been properly installed (welded/bolted) and that it has not mechanical or corrosion damage.





Measure the outer diameter of the cable and ensure that diameter is within the cable/pipe range marked on the front of the block or by the colour code of the block.



Check that the HRT/HRTO is completely inserted in the Sleeve/Aperture.





Check that the HRT/HRTO is completely inserted in the Sleeve/Aperture.





Check that stayplates have not be used in the installation.


Check that HTS Lubricant has been used during the installation.



Check that front plates have been closed.





Check that there are sufficient blocks installed into the frame to cover the sealing area defined for each size of frame.



TYPE	SEALING AREA (mm)
HTO-30	15x15
HTO-40	20x20
HTO-50	30x30
HTO-70	40x40
HTO-100	60x60
HTO-125	80x80
HTO-150	90x90
HTO-200	120x120

Check that the right tightening of the bolts have been performed (approximately 10 mm of thread on each bolt should protrude from the nut).



→ Notes

Leave the system at least 24 hours before apply pressure.

Check that there are sufficient blocks installed into the frame to cover the sealing area defined for each size of frame.